

NO LIMIT

QUALITY HOT ROD PARTS
&
ENGINEERING

47-54 CHEVY PICKUP GLASS KIT

You're lucky! This is an easy one.

You will need to cut a template board to fit the front channel into place. We use a piece of 1/4" hardboard wood cut 12" x 28 3/4". The 28 3/4" width is VERY IMPORTANT. The 12" height can be 10" – 14". You cut the template square.

We recommend cutting a 14" x 14" hole in the door. The hole should be a little bit forward and higher than dead center. This is not too critical – see the picture. This piece can be put back in if you are using stock window regulators. If you are installing power windows, leave it out.

Feed the template in from the top. Fit the forward channel in and square up the template against the stock rear channel. Push the new forward channel up and back against the template. This will locate the forward channel. Drill two holes for the lower mount. There is no need to secure the top.

Fit in the run channel and glass. Slide the glass up and down to check the fit. Adjust the lower mount, if needed.

For final assembly, use 3M weather-strip adhesive to hold in the channel, wiper (outside), and the felt (inside).

