



55-59 CHEVY ONE PIECE GLASS

1. Remove all of the stock glass, felt channels ect.
2. Modify the division bar- measure up from the bottom 24" and cut. Trim the sides back to about 45 degree angle. – **FIG. 1**
3. Drill two new division bar lower mount holes -- 6 1/2" forward of the stock holes. Drill out to 7/16" to allow some adjustment. Mount bar into place- weld or rivet top.
4. Attach glass into the mechanism channel.
5. Install felt channel around door. Spacers may be required **FIG. 2** Adjust as needed.

